

INTUITOUS CONTROLLER CONFIGURATION WORKSHEET: ECC-HS

Switch #	Switch Position	Function	Description
<i>Select Temperature Setback for Heating</i>			
1	<input type="checkbox"/> On <input type="checkbox"/> Off	Heating Setback	These 2 switches are used to select the heating temperature setback using the following 4 combinations: Off-Off=62F (17C), Off-On=64F (18C), On-Off=66F (19C), On-On=68F (20C)
2	<input type="checkbox"/> On <input type="checkbox"/> Off		
<i>Select Temperature Setup for Cooling</i>			
3	<input type="checkbox"/> On <input type="checkbox"/> Off	Cooling Setback	These 2 switches are used to select the cooling temperature setback (also referred to as setup) using the following 4 combinations: Off-Off=Off, Off-On=80F (27C), On-Off=78F (26C), On-On=76F (24C)
4	<input type="checkbox"/> On <input type="checkbox"/> Off		
<i>Enable other Features and Timers</i>			
5	<input type="checkbox"/> On <input type="checkbox"/> Off	Daytime Restore	If enabled, the heat/cool system will exit setback once the daytime restore timer has expired. This feature allows the heat/cool system to exit conservation mode in time to heat/cool the house back to comfort level before the homeowner returns from work. If disabled, setback will continue until occupancy is re-established (I.e. AWAY is turned off). On = Enabled, Off = Disabled
6	<input type="checkbox"/> On <input type="checkbox"/> Off	Daytime Restore Time	This switch is used to set the daytime restore timer to 6 hours or 8 hours. Note that switch #5 must be on for this setting to take effect. On = 6 hours, Off = 8 hours
7	<input type="checkbox"/> On <input type="checkbox"/> Off	Night Restore	If enabled, the heat/cool system will exit setback once the night restore timer has expired. This feature allows the heat/cool system to exit conservation mode in time to heat/cool the house back to comfort level before the homeowner wakes. If disabled, setback will continue until the alarm is disabled (I.e. STAY is turned off). On = Enabled, Off = Disabled
8	<input type="checkbox"/> On <input type="checkbox"/> Off	Night Restore Time	This switch is used to set the night restore timer to 6 hours or 8 hours. Note that switch #7 must be on for this setting to take effect. On = 6 hours, Off = 8 hours
9	<input type="checkbox"/> On <input type="checkbox"/> Off	Long Term Setback	When enabled, the system will enter the long term conservation mode when the space has been Vacant (alarm in AWAY mode) for 18 hours and longer. The setback temperature is the Vacant setback setting minus 3F for heating and plus 3F for cooling. On = Enabled, Off = Disabled
10	<input type="checkbox"/> On <input type="checkbox"/> Off	Exit Delay	This switch is used to set the exit delay to 0 minutes (immediate) or 20 minutes. The delay will prevent the heating and cooling system from entering setback mode until the delay timer has expired. On = 20 minutes, Off = 0 minutes

Note: Factory defaults denoted in **Bold Red** font.